

PiCorePlayer Instructions

Powering Up the PecanPi™ Streamer Ultra

1. Make all audio connections to the device.
2. Connect ethernet.
3. Connect power.
4. The device can take up to 60 seconds to boot up.
5. Once the device is booted up, it can be controlled through LMS and associated apps like Squeezer.

Powering Down the PecanPi™ Streamer

Access the web interface per instructions below and shutdown the software, then wait 30 seconds and remove power.

PecanPi™ Streamer Volume Control

The knob on the front of the unit controls volume.

- Knob fully clockwise – volume at 0dB (max volume)
- Knob fully counter-clockwise – device muted

If using the knob, set LMS volume to 100% for best performance.

If you want to use the software volume control built into LMS, turn the knob fully clockwise.

S/PDIF Operation

The S/PDIF input has an automatic switch over that takes audio from the S/PDIF connection when there is a valid signal. When no valid signal is available on the S/PDIF interface the device defaults back to taking streaming data from Volumio.

When operating from the S/PDIF interface the volume can only be controlled using the knob.

PiCorePlayer Instructions

Wi-Fi Instructions

If you don't have an ethernet connection next to the streamer adding one is easy with either of these products that many of my customers use:

[TP-Link AC750 Wi-Fi Bridge and Extender - For 5G](#)

[TP-Link 300Mbps Wi-Fi Bridge and Extender - For 2.4G](#)

pCP Web Interface

Advanced settings can be accessed through the device's web interface. To access this interface put the device's IP address into a browser in the following format:
http://XXX.XXX.XXX.XXX

Example

http://192.168.1.78