



Orchard Audio

Thank you for your support!

Starkrimson® Mono Ultra Premium Instructions

Danger High Voltage:

The amplifier outputs (speaker terminals) can be up to 80V, do not touch while the amplifier is on.

Notes:

1. Do not make or break the connections to the amplifier while it is on.
2. Due to the bridged amplifier design both speaker terminals are hot when the amplifier is on.
 - Do not connect either of the speaker terminals to ground/earth ground.
3. There are no user-serviceable parts, opening the amplifier will void the warranty.

To turn the amp on:

- Connect Speaker.
- Connect XLR Input.
- Plug the power cord into the amplifier.
- Turn it on by firmly pressing switch into the ON (I) position, the switch will make a click when fully engaged.
 - It may take up to 30 seconds for the amplifier to become active.

To turn the amp off:

1. Turn off by pressing the switch into the OFF (O) position, the switch will make a click when fully disengaged.

Amplifier Protection Circuits

- Thermal – If the amplifier overheats it will turn off until it is cool enough to continue operation.
- Overload – If overload occurs, the amplifier will turn off for 20 seconds and then turn back on.
- Circuit Breaker – The On/OFF switch is also a circuit breaker, in a scenario where it turns itself OFF (O), wait at least 5 minutes before turning back on. If it turns OFF (O) a second time please contact us.

How do you like them apples?

Rev 1.0